

Thank you for purchasing the FS-3 kit. The kit should include the following:

16 x M10 - 1.5 x 45 cm

16 x washer

16 x locking washer

4 x flat plate

1 x eye bolt M10 - 1.5 x 35 mm

2 x MB50

Below is an illustration of how the plates and brackets attach to your Danley Sound Labs loudspeaker. The purpose of the kit is to link three speakers together in the recommended configuration.

- Start by placing the loudspeakers upside down with the sides packed together tightly and symmetrically aligned.
- On the top remove the M10 bolt with a 6 mm hex key where the plate bolts are shown.
- Place the flat plates over the holes spanning one cabinet to the other and secure tightly with a bolt and washers.
- Carefully flip the loudspeakers over and repeat the process on the top, this time securing the MB50 fly bars.
- Insert eye bolt in lower rear rig point for pull back cable.

