

Thank you for purchasing the FSDFA-1 kit. The kit should include the following:

6 x M10 - 1.5 x 45 cm

6 x washer

6 x locking washer

3 x flat plate

Below is an illustration of how the plates attach to your Danley Sound Labs loudspeaker. The purpose of the kit is to link a DFA and SH50 together in the recommended configuration.

-Start by placing the SH50 on top of the DFA.

-Remove the M10 bolt with a 6 mm hex key where the plate bolts are shown below.

-Place the flat plates over the holes, spanning one cabinet to the other and secure tightly with a bolt, and washers.

-Repeat this process on all three sides.

