

Thank you for purchasing the MBA-3 kit. The kit should include the following:

11 x M10 - 1.5 x 45 cm

11 x washer

11 x locking washer

4 x flat plate

1 x angle plate

Below is an illustration of how the plates attach to your Danley Sound Labs loudspeaker. The purpose of the kit is to link three speakers together in the recommended configuration.

- Start by placing the loudspeakers upright with the sides packed together tightly and symmetrically aligned.
- On the top remove the M10 bolt with a 6 mm hex key where the plate bolts are shown.
- Place the flat plates over the holes spanning one cabinet to the other and secure tightly with a bolt and washers.
- Repeat this process on the back using the angled plate.

