

Thank you for purchasing the MBA-2 kit. The kit should include the following:

16 x M10 - 1.5 x 45 cm

16 x washer

16 x locking washer

4 x OFW bars

Below is an illustration of how the J-Series Outer Fly-Ware attach to your Danley Sound Labs loudspeaker. The purpose of the kit is to attach load rated rigging points to the loudspeaker.

- For safe rigging, the OFW kit must be attached to the loudspeaker.
- Remove the M10 bolts with a 6 mm hex key on both sides of the speaker.
- Align the OFW bar with the mounting holes and secure tightly with a bolt, locking washer and washer.
- The 3/4" hole is the top rigging point and should stand off about 3".
- Repeat this process on both side in all four positions.

Bumper Bar

To attach the bumper bar align the 3/4" holes on the top of the OFW bars and use the 3/4" bolts, washers, and nuts to secure the bar to the outer flyware.

