

Thank you for purchasing the MBA-3 kit. The kit should include the following:

16 x M10 - 1.5 x 45 cm

16 x washer

16 x locking washer

8 x flat plate

1 x eye bolt M10 - 1.5 x 35 mm

Below is an illustration of how the plates attach to your Danley Sound Labs loudspeaker. The purpose of the kit is to link three speakers together in the recommended configuration.

- Start by placing the loudspeakers upside down with the sides packed together tightly and symmetrically aligned.
- On the top remove the M10 bolt with a 6 mm hex key where the plate bolts are shown.
- Place the flat plates over the holes spanning one cabinet to the other and secure tightly with a bolt and washers.
- Carefully flip the loudspeakers over and repeat the process on the top.
- Insert eye bolt in lower rear rig point for pull back cable.

