

Preparing the Amplifier

1. Unzip the contents of the downloaded folder if you have not already done so.
2. Connect your amplifier to your PC using the appropriate cable.
3. Wait until the Online light on the face of the amplifier stops blinking.
4. Launch the System Engineer software.
5. Click the "Go Online" button on the left side.
6. Double-click the device to launch the control panel.

Loading the DSE File

7. Select the Open icon on the left side menu bar.
8. Open the loudspeaker.dse file intended for use in the folder titled **240520 DNA Pro and C Series Individual Presets**.
9. Navigate to the "Setup" tab.
10. If the preset loaded properly, you will find the name of the loudspeaker under the input section. This process will overwrite only the active channels, without affecting existing preset files.

Saving Settings to Amplifier

1. **Store Presets:**
 - Under the "Module Preset Recall" menu, select the "Store" option.
 - Customize options such as location, custom name, overwrite protection, and component name.
 - Use "Recall Permission" to recall a group of outputs via input module, individual outputs, or both.
2. **Repeat Process:**
 - Repeat the above process until all required presets are locally saved to your amplifiers.
3. **Backup Custom Library:**
 - Once you have compiled a custom library, save the progress.
 - Use the "Save" button or "File Save As" option to create a backup or clone file for loading onto other amplifiers.

Handling Memory Slots

- If more memory slots are needed than available:
 - Select "Revert to Factory Settings" under the bottom right "hamburger" menu.
 - Refresh the module to clear all factory settings. Repeat if necessary.