



• = Attachment Point Symbol
 ⊙ = Center of Gravity Symbol

Attachment Points
 M10-1.5 Thread:
 (4) on Top
 (4) on Bottom
 (8) on Rt Side
 (8) on Left Side



DSL Supplied Bars
 Must Be Used
 When Suspended:
 SEE NOTE



Isometric View




Front View



Back View

Rear Access Panel

I/O Panel



Bottom View

Optional Caster Board:
 2 at Rear are Locking

Skid Runners:
 2 Places

Handle:
 12 Places

Note: Attachment Points are for securing Cabinet to External Rigging Frame. Rigging Frame shall support Cabinet such that Attachment points are not under load. Rigging Frame should carry the full load of this cabinet. Attachment points are for securing cabinet to the inside of External Rigging Frame. Attachment points are not to be used for suspension of this cabinet.

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF QUALITY MUSICAL SYSTEMS, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF QUALITY MUSICAL SYSTEMS, INC. IS PROHIBITED.

MATERIAL
FINISH
DO NOT SCALE DRAWING

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 TOLERANCES:
 FRACTIONAL ±
 ANGULAR: MACH ± BEND ±
 TWO PLACE DECIMAL ±
 THREE PLACE DECIMAL ±

DRAWN	TBW	2/25/2014
ENG APPR.		
MFG APPR.		
Q.A.		

Danley Sound Labs		
TITLE:	J194	
SIZE A	Plan View	REV 4
Last Save Date: Tuesday, February 25, 2014 1:05:27 PM		