

## Amp Note 004

### Loading presets into the DNA 5K4c amplifier

The DNA 5K4c amplifier is different from the DNA Pro amplifiers in that it does not store a library of presets for recall. The desired settings must be loaded into the amplifier on a case by case basis. Please contact Danley Sound Labs for the appropriate preset file for any given configuration.

Loading the preset into the amplifier is a fairly simple process. It is outlined here:

1. Download the preset file to the computer where it can be found later.
2. Connect the computer to the DNA 5K4c amplifier via USB or BVNet.
3. Open the amplifier panel.
4. Go to File and choose Open, or click on the Open icon in the left-hand toolbar.
5. Browse to the preset file location on the computer.
6. Select the preset and choose Open
7. Please wait while the settings are loaded into the amplifier.

The preset values for the configuration are stored in the output DSP for each channel. These settings can be viewed by expanding the window and switching to the Crossover/Gain page and EQ Out pages. There are additional EQ, delay, and crossover DSP available on the input EQ/Delay pages which can be used for system integration and tuning the loudspeakers to the room.

